


Residual current monitor RCMA470LY

AC/DC sensitive residual current monitor for TN and TT systems (AC, DC and pulsed DC currents)





Residual current monitor RCMA470LY

AC / DC sensitive residual current monitor for TN and TT systems (AC, DC and pulsed DC currents)



Device features

- External measuring current transformer
- Two separately adjustable response values, Alarm I_{Δn1}: 30 mA...3 A (0...150 Hz), prewarning I_{Δn2}: 50 %/100 % of I_{Δn1}
- Adjustable response delay 0...10 s (prewarning 0/1 s)
- Two separate alarm relays with one changeover contact each
- N/O or N/C operation
- Fault memory
- · Combined TEST and RESET button
- Connection external TEST and RESET button
- LED bar graph indicator $I_{\Delta n}$ 0...100 %
- Connection external measuring instrument $I_{\Delta n}$ 0...100 %
- CT connection monitoring
- · Sealable transparent cover
- Separate supply voltage
- Type B acc. to IEC 60755

Approvals



Product description

The AC/DC sensitive residual current monitor RCMA470LY is designed for monitoring earthed power supply systems (TN and TT systems) where DC fault currents or residual currents continuously greater than zero may occur. These are in particular loads containing six-pulse rectifiers or one way rectifiers with smoothing, such as converters, battery chargers, construction site equipment with frequency-controlled drives.

The prewarning stage (50% of the set response value $I\Delta n1$) allow to distinguish between prewarning and alarm. Since the values are measured with measuring current transformers, the device is nearly independent of the load current and the nominal voltage of the system. The device can also be used for busbar systems.

Application

- AC/DC sensitive residual current monitoring in earthed two, three or four conductor systems.
- AC/DC sensitive current monitoring of single conductors de-energized under normal conditions (e. g. N and PE conductors).
- Variable-speed drives
- Uninterruptible power supply systems (UPS)

- Construction site equipment
- · Wood working machines
- · Battery systems
- Computer tomographs
- · Laboratory equipment
- Photovoltaic systems
- · Furniture industry
- · Sewage works

Function

Residual current monitoring takes place via an external measuring current transformer. When the residual current respectively the current exceeds the set response value, the alarm LED lights and the associated alarm relay switches when the response delay has elapsed.


The alarm messages are stored. The fault memory can be reset by pressing the RESET button. The device function can be tested using the TEST button.


The currently measured value in per cent related to the set response value is shown on the LED bar graph indicator. The CT circuit is continuously monitored. In case of wire breakage, the alarm relay switches and the Power On LED flashes.





Wiring diagram - system connection, external connections






- Supply voltage U_S (see ordering information), a 6 A fuse recommended for line protection.
- 2 External measuring current transformer W...B
- 3 External measuring instrument
- 4 External TEST and RESET button
- 5 Alarm relay: switches when the fault current exceeds the response value $I_{\Delta n1}$ (alarm) and in case of interruption of the CT connection.
- 6 Alarm relay: switches when the fault current exceeds 50% or 100% of the response value $I_{\Delta n1}$.

Do not route the PE conductor through the measuring current transformer!

Wiring diagram - front plate



- 1 Combined TEST and RESET button: short-time pressing (< 1 s) = RESET, long-time pressing (> 2 s) = TEST.
- Power On LED: lights when the device is in operation and flashes in case of interruption of the CT connection, defective CT or when the measuring range is exceeded.
- 3 Alarm LED: lights when the fault current exceeds the set response value and flashes when 50 % of the set response value are reached.
- 4 LED bar graph indicator, shows the measuring value in per cent related to the preset response value.
- 5 Potentiometer for setting the response delay (0...1 s).
- 6 Potentiometer for setting the response value (x 1...10 mA).

Setting of the DIP switches (white = switch position)

- 7 Prewarning contact 21-22-24
 - A Prewarning at 50% of $I_{\Delta n1}$
 - B Prewarning at 100% of $I_{\Delta n1}$
- 8 Response delay prewarning
 - A Delay 1 s
 - B Delay 0 s
- 9 Alarm relay
 - A N/O operation
 - B N/C operation
- 10 Response range
 - A 30 mA
 - B 100 mA x 1...10
 - C 300 mA

Response delay

- A Setting value ^t/_s x 10
- B Setting value ^t/_s x 1



BP404001

 \leq 350 g

Technical data

Insulation coordination acc. to IEC 60664-1		Switching elements	
Rated insulation voltage	AC 250 V	Number of switching elements	2 x 1 changeover contact
Rated impulse voltage/pollution degree	4 kV/3	Operating principle, adjustable	N/C operation/N/O operation
Valtaga rangas		Electrical endurance, number of cycles	12000
Voltage ranges		Rated contact voltage	AC 250 V/DC 300 V
Supply voltage <i>U</i> _S	see ordering information	Limited making capacity	AC/DC 5 A
Operating range of Us	0.851.1 x <i>U</i> ₅	Breaking capacity	2 A, AC 230 V, $\cos phi = 0.4$
Frequency range of U_S	DC/5060 Hz		0.2 A, DC 220 V, L/R = 0.04 s
Power consumption	≤ 3.5 VA	Fault memory	ON
Measuring circuit/response values		Environment/EMC	
External measuring current transformer	WB series	EMC immunity	acc. to EN 61543
Operating characteristic acc. to IEC 60755	Type B	EMC emission	acc. to EN 61000-6-4
Rated residual operating current $I_{\Delta n2}$ (prewarning)	50/100 % of I _{∆n1}	Shock resistance IEC 60068-2-27 (during operation)	15 g/11 ms
Response delay $t_{\rm v}$	0/1 s	Bumping IEC 60068-2-29 (during transport)	40 g/6 ms
Rated residual operating current $I_{\Delta n1}$ (alarm)	30 mA3 A	Vibration resistance IEC 60068-2-6 (during operation)	1 g/10150 Hz
Response delay t_v , adjustable	010 s	Vibration resistance IEC 60068-2-6 (during transport)	2 g/10150 Hz
Rated frequency	0150 Hz	Ambient temperature (during operation)	- 25+ 70 ℃
Relative percentage error	0 25%	Ambient temperature (when stored)	- 40+ 75 ℃
	approx. 25% of the response value	Climatic category IEC 60721-3-3	3K5
Response time t_{an} at $I_{\Delta n1} = 1 \times I_{\Delta n1/2}$ ($t_v = 0 \text{ s}$)	< 70 ms	Commention	
Response time t_{an} at $I_{\Delta n1} = 5 \times I_{\Delta n1/2}$ ($t_v = 0 \text{ s}$)	< 40 ms	Connection	
Displays		Connection	screw terminals
LED bar graph indicator	0100 %	Connection properties rigid/flexible	0.24/0.22.5 mm ²
LEDs	Power On, prewarning, alarm	flexible with ferrules without/with plastic collar	0.24/0.22.5 mm ²
	r over on, previanning, alarm	Conductor sizes (AWG)	2412
Inputs/outputs		Conductor sizes (AWG)	2412
TEST and RESET button	internal/external	Other	
Cable length external TEST and RESET button	≤ 10 m	Operating mode	continuous operation
Current source for external measuring instrument 01	00 % DC 0400 μA	Mounting	any position
Load	≤ 12.5 kΩ	Protection class, internal components (IEC 60529)	IP30
Cable lengths for measuring current transformers		Protection class, terminals (IEC 60529)	IP20
		Type of enclosure	X470
Single wire ≥ 0.75 mm ²	010 m	Enclosure material	polycarbonate
		Screw mounting	2 x M4
		DIN rail mounting acc. to	IEC 60715
		Flammability class	UL94V-0
		Standards	IEC 62020

Ordering information

Response	Rated	Time	Measuring	Fault	Indication	Supply Supply	Supply voltage U _S		Туре	Art. No.
range I∆n	frequency	delay	current transformers	memory			DC			
30 mA3 A 0150 Hz 0			internal/		230 V	-	RCMA470LY	B 9404 2001 ³⁾		
	0 10 -	WALD WOOD			90132 V ¹⁾	-	RCMA470LY-13	B 9404 2003 ³⁾		
	010 s		RCMA470LY-21	B 9404 2008 ²⁾						
					-	77286 V ¹⁾	RCMA470LY-23	B 9404 2009 ²⁾		

Instruction leaflet Weight

Other supply voltages on request

¹⁾ Absolute values of the operating range, 2) For industrial application only, 3) For industrial and household applications.



Accessories

External measuring current transformers			
Inside diameter (mm)	Туре	Art. No.	
ø 35	W35B	B 9808 0013	
ø 60	W60B	B 9808 0021	

Measuring converter				
Input	Output		Art. No.	
0400 μΑ	010 V / 0/420 mA	RK170	B 9804 1500	


External measuring instrument			
Display range	Size (mm)	Туре	
0100 %	96 x 96	9604-4241	B 986 807

Conditions of operation according to IEC 62020, IEC 60755 amendment 2, Type B $\,$

Type of current	Wave form	Tripping current
Alternating currents (50 Hz)	\sim	0,5 1 x <i>I</i> ∆n
Pulsed DC residual currents (positive and negative half waves) half-wave current	~~~~	0,51,4 x <i>I</i> Δn
Phase-controlled half-wave currents Current delay angle 90° el/135° el	~~ vv	0,5 1,4 x <i>I</i> ∆n
Half-wave current superimposed by a smooth direct current of 6 mA	\longrightarrow	0,51,4 x <i>I</i> _{Δn}
Smooth DC residual current		0,52 x I∆n

Dimension diagram X470

Dimensions in mm





Bender GmbH & Co. KG

P.O. Box 1161 • 35301 Gruenberg • Germany Londorfer Strasse 65 • 35305 Gruenberg • Germany Tel.: +49 6401 807-0 • Fax: +49 6401 807-259 E-Mail: info@bender.de • www.bender.de

